

Ashtray Clock & USB Wiring

Caution! Disconnect Battery prior to attempting installation

Black Wire – To earth/ground on vehicle

Red Wire – To a switched live output either on fuse box or to a switched live behind the dash

Please note – Do not put to a permanent live as this will drain your battery and will cause clock and usb not to switch off when Ignition is in off position

Should you not be confident to install please contact an auto electrician, mini specialist or someone with experience with car electrical systems

